


# Right Connections

towbar wiring kits for the uk




**CITROËN / FIAT / OPEL / PEUGEOT**

**Relay Van & Chassis-Cab 07/2024 >>**  
**Ducato Van & Chassis-Cab 07/2021 >>**  
**Movano C Van & Chassis-Cab 07/2024 >>**  
**Boxer Van & Chassis-Cab 07/2024 >>**

**Part No: FI-054-13M**

## Electric wiring kit for towbars / 13-pin / 12 Volt / ISO 11446 Fitting instructions



### IMPORTANT!

This electric kit has to be installed by a professional workshop or a suitable qualified person.

The installation instructions must have been read and fully understood before the start of any installation. Please contact your wiring kit provider or the hotline shown in the footer should you need assistance!

Make sure the vehicle is approved/homologated by the manufacturer to tow a trailer!

Also please check that there is a definite compatibility between this vehicle and the electric kit!

Following the installation of the electric kit, the fitting instructions should be kept together with the vehicle service document and vehicle handbook. The fitting instructions contain important information relating to the use and function of the towing kit as well as for any diagnostic or activation process, that might have to be repeated in the future (e.g. after the performance of a vehicle software update).

All warranty claims will be forfeited if the electric kit or components contained therein are used incorrectly or modified. If a towing socket adaptor has been used to connect to the trailer or bike rack, this must be removed from the trailer socket once the trailer or bike rack has been disconnected.

If the trailer or bike rack is not equipped with a rear fog lamp, depending on the towing vehicle type, the correct function of the towing kit cannot be guaranteed. In such cases, a rear fog lamp should be retro fitted.

This towing electric kit will not be covered under warranty if any technical or electrical modifications or software updates have been performed by the vehicle manufacturer after the initial commissioning of the kit. That applies especially to modifications or updates which may cause malfunctions in the trailer socket or any other part of the trailer electrical equipment!

Depending on the type of trailer module used in this electric kit, diagnostic interrogation with the vehicle's electrical system may be limited or will not function. The error memory inside the trailer module may not be able to be accessed by vehicle manufacturers diagnostic system.

Error logs relating to the trailer electrical equipment, that may be generated in the vehicle manufacturers diagnostic system as a result of a test procedure, may be due to the incorrect installation of the towing electric kit or the false activation of the trailer module.

**We always recommend whenever possible, the following troubleshooting process:**

→ **An analysis of the vehicle's error memory and possibly clearing of all faults before the start of the installation!**


→ **Try disconnecting the trailer module from the towing harness and re-start the fault clearing process!**

→ **If in doubt, limit the time for troubleshooting to a max of 0,5 hours and call our Technical Support Team!**

Please follow our instructions carefully and always test the towing electrics using a true lighting board or a specifically designed bulb tester. If an LED tester is used, ensure it is equipped with correct load resistors or malfunctions will occur!

This instruction is subject to changes and we reserve the right to make changes to design, colour etc.


All of the data and illustrations may not be an exact representation but the text contained in this instruction must be observed!



**\* OPTION +30/+15**  
**FI050ZC**  
 preparation for

	+30
	+15

- 3x
- 3x
- 3x
- 1x
- 1x
- 1x
- 3x
- 2x
- 2x
- 2x
- 2x
- 2x





## SYMBOL EXPLANATION

	Left (58-L) respectively Right (58-R) tail light
54	Stop light (54) / high mounted, third stop light (54)
	Turn signal indicator left
	Turn signal indicator right
	Rear fog light(s)
	Reversing light(s)
	Permanent power supply / 13pin socket, chamber 9
	Charging wire for trailer battery / 13pin socket, chamber 10
	Trailer / trailer recognition
<b>B+ / 30</b>	Permanent current power supply
	Ground or Earth (31)
	Ground connection battery terminal lug
	Positive connection battery terminal lug

	Cigarette lighter / accessory socket
	Loudspeaker / buzzer
	Park Distance Control
	Switch / source of function
	Connect together
	Disconnect
	Look at / See further information
	Look carefully at selected area
	Present / Occupied / OK
	Not present / Not occupied / Not OK
	Acoustic indication
	Attention / important advice
	Fuse / fuse capacity 20 Ampère

## TOOLS



### ATTENTION!

The vehicle's cooling capacity may have to be increased when retrofitting a trailer coupling!  
You must observe the manufacturer's instructions!!



Note: It may be necessary to check if this vehicle has a stored radio code before disconnecting the battery!








### ATTENTION!

In order to avoid mal-functions and damage to the vehicle's electrical system the earth terminal **must be disconnected** from the vehicle's battery **before starting work!**







Both the trailer module and the vehicle's control unit for the electrical system can be damaged during work on the data bus connections if the battery is not disconnected!

1

Please pay attention to the manufacturer's instructions when disconnecting and reconnecting the vehicle's battery!





2




**SEAL WITH SILICONE.**




3



4



5




6

# SOCKET CONNECTION





Page 24

7





**OPTIONAL:**  
Extension kit  
Pin 9, 10, 11 & 13




**Right**  
Connections part no.  
**FI050ZZC**


8





9



1




2



3



**CAN CHECK**

Page 23





4


10





11





2



12




2



13

**OPTION 1**

With →




15 → 22

27 → 45

14

**OPTION 2**


With →



23 → 45




**OPTION 1**




1

2




3




15

**OPTION 1**




16

**OPTION 1**




17

**OPTION 1**




18

**OPTION 1**




19

**OPTION 1**




20

**OPTION 1**




21

**OPTION 1**




22



**OPTION 2**



➔ **Page 23**



**⚠ Please note different wire-size slots in CANbus connector!**

0.35 mm<sup>2</sup>      0.5-0.75 mm<sup>2</sup>

Blue or White

Black

C1

**CAN L**      White or White/Black Pos. 42

**CAN H**      Blue or White Pos. 43

**⚠ Please note different wire-size slots in CANbus connector!**


0.35 mm<sup>2</sup>      0.5-0.75 mm<sup>2</sup>

White or White/Black


Yellow

C1





23




**OPTION 2**





**STOP**      Green/Black or White/Purple Pos. 49






24



**OPTION 2**




 Brown/Black  
or  
White/Green  
Pos. 18




25

**OPTION 2**



26



**Vehicles with factory fitted PDC system**

**OPTION 1**

**Rear Sensors Only!**




28 → 30

**OPTION 2**

**360° PDC**



31 → 33




**Vehicles without factory fitted PDC system**







34

27



**OPTION 1**





**Rear Sensors Only!**



**OPTION 1A**




**OPTION 1B**




**OPTION 1A** (PIN 8 is free)


1




2



3




4




29

**OPTION 1B** (PIN 8 is occupied)


2




3




4



5




6






30




**OPTION 2**



**360° PDC**



**Option 2A**



**connector A  
12 pole**

**PIN 8 is free**




32

35

→ 45

**Option 2B**



**connector A  
12 pole**

**PIN 8 is occupied**



33


35

→ 45


31

**OPTION 2A** (PIN 8 is free)


1




2



3




4




32

**OPTION 2B** (PIN 8 is occupied)


1




2




3




4




5




6




33




34



35



36






**Optional**



Trailer Simulator for 7- and 13-pin Sockets


37

**Functional test**




38

Trailer turn indicator failure – display & indicator light substitution




**C2** Turn Indicator Substitution




39

In case of trailer turn indicator failure:  
Corresponding tail light will take over the indicator light function.






40






Please note: Limited functionality of assistance systems!




41

Optional

Adapter socket




13-pin





7-pin

Right Connections part no. AD137




42



43


# CAN CHECK



The faultless connection of the trailer module to the vehicle-side CAN-bus can be checked quick and easy with the ECS CAN-check:



1. Connect a trailer, load carrier or test device to the trailer socket
2. Interrupt power supply to trailer module for at least 10 seconds
3. Switch on ignition
4. CAN bus active display: Regular double-sided flashing of the trailer tail lights
5. Switch off ignition, close all doors and hoods, wait for CAN-bus sleep mode
6. CAN bus sleep mode display: Alternate lighting of the trailer tail lights

44



45

## SOCKET CONNECTION



## SOCKET CONNECTION

**Optional: Right**  
Connections part no.  
**FI050ZZC**

DIN/ISO 11446													
Pmax	21W	21W		21W	52W	3x21W	52W	21W	180W/15Amp.	180W/15Amp.			
Colour	Yellow	Blue	White	Green	Brown	Red	Black	Pink	Orange	Grey	White/Black	-	White/Red