

Mercedes-Benz


| | |
|---|------------|
| C-Class Saloon (W206) | 06/2021 >> |
| C-Class Saloon Hybrid/PHEV (W206) | 06/2021 >> |
| C-Class Estate (S206) | 06/2021 >> |
| C-Class Estate Hybrid/PHEV (S206) | 06/2021 >> |
| C-Class Estate All-Terrain (X206) | 11/2021 >> |
| C-Class Estate All-Terrain Hybrid/PHEV (X206) | 11/2021 >> |
| CLE Cabrio (A236) | 02/2024 >> |
| CLE Coupe (C236) | 02/2024 >> |
| E-Class Saloon (W214) | 06/2023 >> |
| E-Class Estate (S214) | 09/2023 >> |
| E-Class Estate All-Terrain (X214) | 01/2024 >> |
| GLC (X254) | 09/2022 >> |
| GLC Hybrid (X254) | 09/2022 >> |
| GLC Coupe (C254) | 07/2023 >> |
| GLC Coupe Hybrid (C254) | 07/2023 >> |

**Right
Connections**

towbar wiring kits for the uk

Part No: MB-108-07

Electric wiring kit for towbars / 7-pin / 12N / 12 Volt / ISO 1724 Fitting instructions



IMPORTANT!

This electric kit has to be installed by a professional workshop or a suitable qualified person.

The installation instructions must have been read and fully understood before the start of any installation. Please contact your wiring kit provider or the hotline shown in the footer should you need assistance!

Make sure the vehicle is approved/homologated by the manufacturer to tow a trailer!

Also please check that there is a definite compatibility between this vehicle and the electric kit!

Following the installation of the electric kit, the fitting instructions should be kept together with the vehicle service document and vehicle handbook. The fitting instructions contain important information relating to the use and function of the towing kit as well as for any diagnostic or activation process, that might have to be repeated in the future (e.g. after the performance of a vehicle software update).

All warranty claims will be forfeited if the electric kit or components contained therein are used incorrectly or modified. If a towing socket adaptor has been used to connect to the trailer or bike rack, this must be removed from the trailer socket once the trailer or bike rack has been disconnected.

If the trailer or bike rack is not equipped with a rear fog lamp, depending on the towing vehicle type, the correct function of the towing kit cannot be guaranteed. In such cases, a rear fog lamp should be retro fitted.

This towing electric kit will not be covered under warranty if any technical or electrical modifications or software updates have been performed by the vehicle manufacturer after the initial commissioning of the kit. That applies especially to modifications or updates which may cause malfunctions in the trailer socket or any other part of the trailer electrical equipment!

Depending on the type of trailer module used in this electric kit, diagnostic interrogation with the vehicle's electrical system may be limited or will not function. The error memory inside the trailer module may not be able to be accessed by vehicle manufacturers diagnostic system.

Error logs relating to the trailer electrical equipment, that may be generated in the vehicle manufacturers diagnostic system as a result of a test procedure, may be due to the incorrect installation of the towing electric kit or the false activation of the trailer module.

We always recommend whenever possible, the following troubleshooting process:

- An analysis of the vehicle's error memory and possibly clearing of all faults before the start of the installation!
- Try disconnecting the trailer module from the towing harness and re-start the fault clearing process!
- If in doubt, limit the time for troubleshooting to a max of 0,5 hours and call our Technical Support Team!

Please follow our instructions carefully and always test the towing electrics using a true lighting board or a specifically designed bulb tester. If an LED tester is used, ensure it is equipped with correct load resistors or malfunctions will occur!

This instruction is subject to changes and we reserve the right to make changes to design, colour etc.

All of the data and illustrations may not be an exact representation but the text contained in this instruction must be observed!

MB C-Class W/S/X 206



MB CLE A/C 236

MB E-Class W/S/X 214

MB GLC X254



ADVANCED DRIVER
ASSISTANCE SYSTEMS




This kit does not support any of the assistance systems of the vehicle.
Vehicle assistance systems may have to be deactivated manually when towing a trailer!

MB C-Class W/S/X 206

MB CLE A/C 236



MB E-Class W/S/X 214

MB GLC X254



Please note that the operation of the electric tailgate will continue to function with a bicycle carrier/trailer/caravan attached. It must be operated manually.



INFO




SYMBOL EXPLANATION

| | | | | | |
|-----|---|--|--|--------------------|---|
| 58L | Left taillight (58-L) | | Ground or Earth (31) | | Not present / Not occupied / not OK |
| 58R | Right taillight (58-R) | | Ground connection battery terminal lug | | Left |
| 54 | Stop light (54) / high mounted, third stop light (54) | | Positive connection battery terminal lug | | Right |
| | Turn signal indicator left | | Fuse / fuse capacity 20 Amp | | Acoustic indication |
| | Turn signal indicator right | | Loudspeaker / buzzer | | Attention / important advice |
| | Rear fog light(s) | | Park distance control | | Reuseable |
| | Reversing lights(s) | | Switch / source of function | | Trash bin |
| | Permanent power supply / 13pin socket, chamber 9 | | Connect together | | Use tape |
| | Charging wire for trailer battery/ 13pin socket, chamber 10 | | Disconnect | | Option |
| | Trailer / Trailer recognition | | PDC cut off | | Information |
| | Permanent current power supply | | Look carefully at selected area | | Measure the voltage |
| | Voltage after ignition | | Present / Occupied / OK | NO NC COMMON | Normally open Normally close Common |

TOOLS



ATTENTION! The vehicle's cooling capacity may have to be increased when retrofitting a trailer coupling!
You must observe the manufacturer's instructions!!



Note: It may be necessary to check if this vehicle has a stored radio code before disconnecting the battery!




ATTENTION! In order to avoid mal-functions and damage to the vehicle's electrical system the earth terminal **must be disconnected** from the vehicle's battery **before starting work!**

Both the trailer module and the vehicle's control unit for the electrical system can be damaged during work on the data bus connections if the battery is not disconnected!

Please pay attention to the manufacturer's instructions when disconnecting and reconnecting the vehicle's battery!

1


All models



2


All models

Keyless-go




3

C-Class Saloon / CLE





4

C-Class Estate



5


C-Class Estate



6


6/25

E-Class Saloon




7

E-Class Estate




8

GLC






9

GLC




10



C-Class




1



11






1



12




E-Class Saloon



13




! SEAL WITH SILICONE.

E-Class Estate



14

! SEAL WITH SILICONE.



15

2


3

4

SEAL WITH SILICONE.

15

16




SOCKET CONNECTION




Page 25

INFO


17





18




19




20




21







22



23







C-Class / CLE





24

C-Class





25

13/25





26

E-Class Saloon





27

E-Class Estate



28



E-Class Estate



29



15/25

GLC





30

GLC









31

16/25



B+/30



Option 1

Choose any free position



33



Option 2

No free position









34 → 35

32



Option 1

Choose any free position





33

17/25

Option 2

No free position





34



Option 2

No free position

Option A









Option B




35

18/25







42

Optional




Right
Connections
towbar wiring kits for the uk



Trailer Simulator for 7- and
13-pin Sockets


43




44

21/25


Reverse signal preparation






Reverse signal preparation







Reverse signal preparation



Functional test



45



46





PDC to be deactivated manually!



Parkinglight function not supported!



Coming / leaving home not supported!

47






Optional


Adapter socket



48





49



50

24/25

SOCKET CONNECTION



SOCKET CONNECTION

| DIN/ISO 1724 | ◀ L | 0 2 | 1-7 | R ▶ | 5 58- | STOP | 5 58- |
|--------------|--------|------|-------|-------|--------|-------|--------|
| | 1/L | 2 | 3/31 | 4/R | 5/58-R | 6/54 | 7/58-L |
| Pmax | 21W | 42W | | 21W | 52W | 3x21W | 52W |
| | Yellow | Blue | White | Green | Brown | Red | Black |